





















HSE INSTRUCTION FOR VISITORS

RollDock Shipping BV requires from any supplier, subcontractor or sublet subcontractor to familiarize themselves with the following HSE requirements and comply with them.

These requirements are applicable when entering a restricted quayside and/or vessel.
Any deviation will be reported and is subject to penalties to supplier or subcontracting party

PPE TO BE WORN AT ALL TIMES		SPECIFIC PPE REQUIREMENTS	
 Safety Helmet  Safety Glasses		When working above 2.0 meter / 6 feet :	
 Protective footwear  High visibility jacket		 Safety harness must be worn	
 Long sleeves work clothes  Adapted working gloves		When working within 1.5 meter from quay edge :	
Supplier and (sublet) subcontractor are required to bring their own PPE .		 Lifejackets to be worn	
		AND other additional PPE based on job safety risk assessment or vessels instructions.	
ADDITIONAL REQUIREMENTS			
At arrival and departure: <ul style="list-style-type: none"> ✓ Supplier, (sublet) subcontractor or representative has to report himself to the quayside security at the gate and vessel security at the gangway. ✓ Identification is required. ✓ ISPS badge received from the vessel to be worn at all time when onboard and to be returned to the gangway watch at departure. 		Driving and parking on restricted quayside: <ul style="list-style-type: none"> ✓ Do not park alongside the vessel. ✓ It is not allowed to use a cell phone while driving. ✓ Do not exceed the allowed maximum driving speed. ✓ Comply with site / terminal rules 	
	Use the correct (hand)tool for the job		No Smoking outside dedicated area.
	Keep your workplace clean , tidy and free from obstructions		Vessel is subjected to CCTV surveillance
	Do not enter enclosed spaces		Any person has the right to use the "STOP the JOB" in case unsafe conditions are witnessed
	Do not work under a suspended load		In case of doubts or anything is unclear, speak up – communicate
	Entry to the bridge, the engine room and other restricted areas , is only allowed after permission		Use the waste bins available throughout the vessel.
	No photographs or filming except when permitted by the Master		Work to be carried out only under supervision of RollDock crew and/or staff